

DEVICE CRADLE

No Tools Required



Assembling the Device Cradle:

- 1** | Loosen the socket bolt on the reverse of the Device Cradle (fig.1)
- 2** | Insert the lower stem ball into the socket (fig.2)
- 3** | Turn the socket bolt clockwise to tighten fully and secure it in place



Fitting the Device Cradle:

- 4** | Slide the lower stem into the Accessory Station housing until it clicks (fig.3)



Using the Device Cradle:

- 5** | Release the locking clip on the reverse of the Device Cradle (fig.4)
- 6** | Insert your device, clamp tightly in place and close the locking clip (fig.5)
- 7** | Adjust the angle and orientation of the cradle using the adjustment screws (fig.6)

